

# Pillar Of Fire

---

## Creations Woodshop Class

[www.youngfoundations.org/creations](http://www.youngfoundations.org/creations)



Lesson.....page 2

Tutorial.....pages 3-11

# Lesson

## Scripture:

Psalm 46:10

10 Be still, and know that I am God: I will be exalted among the heathen, I will be exalted in the earth.

## Quotes:

60-0328 IS.THERE.ANYTHING.TOO.HARD.FOR.THE.LORD\_ TULSA.OK MON-DAY\_

19 While Abraham went to meet Them, he turned Them aside and said, “Come in and set down. Set under the oak a little while and let me fetch a little water and wash Your feet, and I’ll give You a morsel of bread. And just rest a little bit, then You may go on Your way.” Oh, when he set Him down there, though they didn’t look any different from any other men, because They were dressed, dust on their clothes and come from some other country, probably their feet dusty and their clothes ragged, but Abraham knew inside there, there was something real. The Spirit declared it. Why? He kept hisself in a spiritual atmosphere all the time, that he could recognize right from wrong, all the time.

That’s the way the Christian ought to do today, is keep yourself prayed up, under a spiritual atmosphere. Always—never seeing the—the bad side, looking to the good side. You are children of God, expecting His blessings.

# Pillar Of Fire Tutorial

## Tools Needed

- Bandsaw
- Measuring tape
- Sand paper
- Safety glasses
- Pin nail gun
- Table saw
- Miter saw

## Materials Needed

- Assorted wood
- Wood Glue
- 3/4” pin nails
- Wood Finish
- Small bush or twig

\*\*\* Parental assistance recommended.

# Steps

1. Cut out template on  $\frac{1}{4}$ " thick board.



2. Cut base to  $6\frac{1}{2}$ " x 4" x  $\frac{3}{4}$ ".



4

3. Dado  $\frac{1}{4}$ " x  $\frac{1}{4}$ " out of the base  $\frac{3}{4}$ " in on both sides.



4. Sand all pieces.



5



5. Glue and nail the larger flange in the dado.



6. Glue smaller flange to the larger flange, making sure flanges align, with smaller flange resting on the base.



6

7. Cut the back piece to 6 ½" x 3 ¾" x ¼".



8. Round corners and sand the back piece.



7

9. Acetone quote on back piece.



10. Glue and nail the back piece into the dado with the quote facing outwards.



11. Final sand.



12. Glue bush onto the smaller flame.



13. Apply finish.



YOU'RE FINISHED!

